


HWL CORE BARREL SPARE PARTS KIT



	ITEM DESCRIPTION	PART NUMBERS
1-19	HWL CORE BARREL SPARE PARTS KIT	18-00-140
1	SPEARHEAD POINT	16-03-001
2	COMPRESSION SPRING	16-03-002
3	DETENT PLUNGER	16-03-003
4	SOLID DOWELL 7/16" x 1"	16-03-005
5	SPRING DOWELL 1/2" x 2 3/4" - 2 NOS.	18-03-003
6	HWL LATCH - 2 NOS.	18-04-002
7	SOLID DOWELL 1/2" x 2 1/8"	18-03-006
8	ADJUSTING HEX NUT	18-03-010
9	SHUT OFF VALVE - 2 NOS.	18-03-012
10	THRUST BEARING - 2 NOS.	18-03-014
11	BEARING SPINDLE	18-03-016
12	THRUST BEARING	18-03-017
13	NYLOCK NUT - 1" UNC	18-03-019
14	GREASE FITTING	16-03-024
15	RING STOP	18-03-025
16	CORE LIFTER	18-03-026
17	CORE LIFTER CASE	18-03-027
18	RING LANDING	18-02-003
19	STABILIZER RING	18-02-006